Citizens Weather Observing Program (CWOP) Configuration for **Cumulus Software** Users

(Last updated: 13 Aug 2016)

These instructions assume you already have setup Cumulus either for home use, or to upload data to another server (e.g., Weather Underground).

- 1.) Gather Station Location Data
- You will need your Latitude and Longitude in decimal degrees, and Elevation in metres. You may already have this information setup in Cumulus, but latitude will be in Degrees/Minutes/Seconds format. However, this can easily be converted. In Cumulus go to the 'Configuration' drop-down menu, then click on "Station Settings." Make note of your Lat/Lon and Elevation.

Station Type	Program Settings	VP type	VP TCP/IP settings	xAP Settings			
 Vantage Pro Vantage Pro2/Vue 	Confirm shutdown	Serial	TCP Port 22222	Enabled			
© WMR-928	Close on Suspend		IP address				
EasyWeather (using .dat file)	Stop 2nd instance	O USB	0.0.0.0				
WS2300	Restart if upplugged			UID FF 4375 00			
 Fine Offset with UV/Light sensor WMR100 WMR200 	Restart if data stops	© TCP/IP	Discon period 0				
Settings	Location	Logs roll over at					
COM Port 0	deg min s	🔘 9am 💿 midnight					
Use bearing zero when calm	Latitude 31 52 0	Latitude 31 52 07 N Altitude 2011 @ ft					
Calculate 10-min wind average		Use 10am in summer					
Use speed for avg calculation	Longitude 100 50 5	Data log interval					
Calculate dew point	Name	© 1 min					
Calculate wind chill	Description	© 5 mins					
Synchronise Davis clock to PC	Units (0) 10 mins						
Use data logger	Wind Pressure	e Temp	Rainfall	15 mins			
Cumulus pressure trend names	◎ m/s ◎ mb	● °C	mm	20 mins			
VP 1-min barometer update	© mph ◎ lung /b ◎ hPa	Ŭ	Ŭ	30 mins			
Round wind speeds	⊚ kts © in	© °F	🔘 in	Forecast			
EasyWeather interval 0.000 mins	Cumulus forecast						
Easyweather.dat	Appual rainfall	inge units later yo	ur data will be wrong:	Pressure extremes:			
	YTD Amount 0.00	Low 050.00					
Station model	0.00		January 👻	0 mb			
	Year 0	(уууу)		High 1050.00 🔘 in			
Solar							
Sun Inreshold 75 % Sun min 0 W/m* Trans ractor 0.80 Ose B/L OK Cancel Help							

If you do not know your lat/lon and elevation, please see the How-To "Signing up for CWOP" for methods to obtain your station location data: www.weather.gov/media/epz/mesonet/CWOP-SignUp.pdf

2.) Re-calculate Lat/Lon

• A useful page for converting lat/lon from decimal degrees to other formats can be found here: <u>http://www.directionsmag.com/site/latlong-converter</u>

• Enter your Latitude in the proper "Deg, Min, Sec" fields, then click the 'Convert' button.

• Your Latitude will be converted to decimal degrees next to the "DM.m" in the greenish-text box. Make a note of it.

• Next, do the same for longitude.

3.) Get a CWOP Station ID:

With any web browser, fill out the form at: http://www.findu.com/citizenweather/cw form.html

CWOP will require your station elevation in meters. You can convert elevation from feet to meters by multiplying your elevation in feet by 0.3048.

The CWOP website is a little "old-fashioned" and unpolished, and it contains far more information than the average user needs. Don't worry about the parts of the form mentioning "Packet Checking" and "MADIS tech support."

CITIZEN WEATHER PROGRAM REGISTRATION FORM					
To obtain a DW number fill in the form below. You will receive an e-mail reply with your assigned number (similar to "DW1234").					
If you have questions, please contact your software provider, or send email to Randy at NOAA. Several different ways to check your data packets are at Packet Checking.					
If you also send your weather data to another internet site, please contact MADIS technical support so they will be aware of the possibility of duplicate data.					
Thank you for participating in the Citizen Weather Program!					
First name	John				
Last name	Doe				
email	johndoe@anonymous.net				
Nearby town	Hurricane				
State (country if outside US)	WV				
Zip Code (if US)	25526				
Elevation	215 (meters above sea level)				
	Send my DW number!				

- Make sure you use a valid email address (don't worry no SPAM).
- If you are a business or agency, you may wish to use its name in place of "First Name" and "Last Name." Otherwise, use whoever will be the primary contact.

• If you need help with any of these steps, or finding your location or elevation, send an email to: cwop-support@noaa.gov

Latitude / Longitude Conversion This page can be used to convert latitude and longitude coordinates.							
Deg: 106 Min: 38 Sec: 55 Convert							
Degrees: Minutes.M: Convert							
Decimal Degrees: Convert							
DMS 106 38 55 DM.m 106 38.916666666667 D.d 106.6486111111111							

4.) Send the form, then make note of your CWOP Station ID:

Your Citizen's Weather Account Number is: DWxxxx

An email will be sent to John Doe (johndoe@anonymous.net) confirming this number.

5.) Configure Cumulus

• In Cumulus, click on the 'Configuration' tab, then click "Internet." This will bring up the Internet Settings dialog.

• In the section labeled "APRS/CWOP Settings" ... enter your CWOP ID in the *ID* field. This will cause some other fields to automatically populate. Leave *Pass* as - 1, leave *Server* as 'cwop.aprs.net', leave *Port* as 14580, and set the *Interval* to 5 minutes. Click on the *Include Solar rad* checkbox only if you have a solar radiation sensor on your weather station.

• Finally, click on the *Enabled* checkbox, then click the "OK" button.

internet Settings	eather			×
Sites/Options	Files			
Web Site		Web Settings	APRS/CWOP Settings	-Weather Underground
Host name FTP Port	21	Auto Update Use active FTP mode	Enabled	Enabled Include UV
Directory		Delete before upload	Pass -1 Server cwop.aprs.net	 Rapid Fire Send average wind Catch Up
Password		Enable Realtime	Port 14580 Interval 5 mins	Station ID KNMSANTA3
Forum URL	http://sandaysoft.com/forum/	Realtime.txt FTP	Include Solar rad	Password •••••
Webcam URL		Realtime interval 30 secs		Interval 5 mins
Web graphs		PWS Weather	Weatherbug	WOW
Resize	Width 750 Height 300	Enabled	Enabled	Enabled
Twitter Enabled	Interval 60 mins	Include UV Include Solar rad Catch Up	Include UV Include Solar rad Catch Up	Include UV Include Solar rad Catch Up
User	Password			
External Progra	ms	<u> </u>	Publisher ID	
Program	Params	Station ID	Number	Site ID
Realtime Program	Params	Password	Password	PIN Interval 15 mine
Daily	Params			
			ок	Cancel Help

- 6.) Check for Data:
- Browse to the following web address, using your CWOP Station ID at the end: <u>http://www.findu.com/cgi-bin/wx.cgi?call=DWxxxx</u>
- For example, if your Station ID was CW0958, you would enter: <u>http://www.findu.com/cgi-bin/wx.cgi?call=CW0958</u>

Note: It may take up to 15 minutes for data to start appearing. Also Note: The date/time stamp used on the above site is in the form YYYYMMDDhhmmss in UTC time. For example "20120402145210" means April 2, 2012 at 14:52 UTC (and 10 seconds).

7.) Normal Operations.

• Make sure you keep Cumulus running at all times to send data.

8.) MesoWest/MADIS Updates:

• These two data aggregators usually update their station tables on a weekly basis (usually Wednesdays). After several days, data from your station should begin showing up on plots at MesoWest:

http://mesowest.utah.edu/cgi-bin/droman/mesomap.cgi?state=NM&rawsflag=3